



Doc. No. 78-4200-03

# Second-Generation Fast Ethernet Interface Processor (FEIP2) Installation and Configuration

---

## Product Numbers: CX-FEIP2-2TX= and CX-FEIP2-2FX=

This configuration note is a standalone publication that provides instructions for installing and configuring the second-generation Fast Ethernet Interface Processor (FEIP2) in all Cisco 7500 series routers, and in Cisco 7000 series routers using the 7000 Series Route Switch Processor (RSP7000) and 7000 Series Chassis Interface (RSP7000CI). (For specific compatibility requirements, refer to the section "Software and Hardware Prerequisites," on page 3.)

---

**Note** For convenience throughout this publication, FEIP2-2TX and FEIP2-2FX are referred to as *FEIP2*, with specific differences clearly noted.

---

Included in this configuration note are steps for FEIP2 hardware installation and cable connection, and basic FEIP2 configuration steps and examples. A table of contents is included so you can more easily find what you need.

For additional descriptions of interface subcommands and configuration options available for Fast Ethernet (FE) interfaces, refer to the appropriate Cisco IOS software configuration and command reference publications listed in the section "If You Need More Information" on page 2.

---

### Corporate Headquarters

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA

Copyright © 1997–1998  
Cisco Systems, Inc.  
All rights reserved.

## Document Contents

This configuration note includes the following sections:

- If You Need More Information
- Installation Prerequisites, page 3
- What Is the FEIP2?, page 16
- FEIP2 Installation, page 23
- Configuring the Fast Ethernet Interfaces, page 30
- Upgrading FEIP2 Microcode, page 39
- Cisco Connection Online, page 42

## If You Need More Information

The Cisco IOS software running your router contains extensive features and functionality. The effective use of many of many of these features is easier if you have more information at hand. For additional information on configuration, the following documentation resources are available:

- Cisco documentation and additional literature are available in a CD-ROM package, which ships with your product. The Documentation CD-ROM, a member of the Cisco Connection Family, is updated monthly. Therefore, it might be more up to date than printed documentation. To order additional copies of the Documentation CD-ROM, contact your local sales representative or call customer service. The CD-ROM package is available as a single package or as an annual subscription. You can also access Cisco documentation on the World Wide Web at <http://www.cisco.com>, <http://www-china.cisco.com>, or <http://www-europe.cisco.com>.
- Refer to the following modular configuration and modular command reference publications, as appropriate for your configuration:
  - *Configuration Fundamentals Configuration Guide*
  - *Configuration Fundamentals Command Reference*
  - *Wide-Area Networking Configuration Guide*
  - *Wide-Area Networking Command Reference*
  - *Network Protocols Configuration Guide*
  - *Network Protocols Command Reference*
  - *Bridging and IBM Networking Configuration Guide*
  - *Bridging and IBM Networking Command Reference*
  - *Configuration Builder Getting Started Guide*
  - *Troubleshooting Internetworking Systems*
- For hardware installation and configuration information on the Cisco 7000 series and Cisco 7500 series routers, refer to installation and configuration guide that shipped with your router.
- To obtain information about documentation, refer to the following:
  - The Documentation CD-ROM
  - The section “Cisco Connection Online,” on page 42

- Cisco Customer Service at 800 553-6387 or 408 526-7208. Customer Service hours are 5:00 a.m. to 6:00 p.m. Pacific time, Monday through Friday (excluding company holidays). You can also send e-mail to [cs-rep@cisco.com](mailto:cs-rep@cisco.com).
- The *Cisco Information Packet* that shipped with your router.

## Installation Prerequisites

This section provides software and hardware requirements for a successful FEIP2 installation, a list of parts and tools you need to perform the installation, and includes safety and ESD-prevention guidelines to help you avoid injury and damage to the equipment. This section also provides a detailed description of the online insertion and removal (OIR) function to help you perform online installation successfully and avoid error message and system restarts. If you are installing a new FEIP2, and, therefore, preparing your site and planning network connections, be sure to review the Fast Ethernet descriptions and interface cable distance limitations, in the section “Fast Ethernet Overview” on page 9.

## Software and Hardware Prerequisites

The FEIP2 operates with the CyBus in the Cisco 7500 series and requires that the host routers are running Cisco IOS Release 11.1(10)CA or later.

The FEIP2 operates with the CxBus in the Cisco 7000 series routers providing these routers have the 7000 Series Route Switch Processor (RSP7000) and 7000 Series Chassis Interface (RSP7000CI) installed, and requires that the host routers are running Cisco IOS Release 11.1(10)CA or later. For proper operation with the FEIP2, we recommend that your RSP or RSP7000 has at least 32 MB of DRAM.

---

**Important Note** To boot a Cisco IOS image over the network after you install a new FEIP2, you must upgrade the boot-loader image that is installed in Flash memory on your RSP to Version `rsp-boot-mz.111-10.CA.bin`, or later.

Instructions for downloading this boot-loader image are available with the boot-loader image on Cisco Connection Online, in the directory `/111-10/`. After you install the new boot-loader image in Flash memory, issue the **reload** command to boot the appropriate Cisco IOS release subset image for your system. Refer to Table 1 for the specific Cisco IOS Release 11.1(10)CA subset images that are available on CCO, in the directory `/111-10/`, and which support the operation of the FEIP2. Refer to the section “Cisco Connection Online,” on page 42, for information on accessing CCO.

---

**Table 1 Cisco IOS Release Subsets for FEIP2 Compatibility**

Cisco IOS Subset Images	Description
<code>rsp-ajv-mz.111-10.CA.bin</code>	Enterprise plus APPN
<code>rsp-jv-mz.111-10.CA.bin</code>	Enterprise
<code>rsp-pv-mz.111-10.CA.bin</code>	Internet Service Provider

### List of Parts and Tools

You need the following tools and parts to install or upgrade an FEIP2. If you need additional equipment, contact a service representative for ordering information.

- CX-FEIP2-2TX(=) or CX-FEIP2-2FX(=), and at least one available interface processor slot in your Cisco 7000 series or Cisco 7500 series router (For specific compatibility requirements, refer to the section “Software and Hardware Prerequisites” on page 3.)
- Cables appropriate for the FE interfaces on your FEIP2; Cisco Systems does not supply Category 5 UTP RJ-45 cables, MII cables, or SC-type cables; these cables are available commercially. (For specific cable requirements, refer to the section “FEIP2 Receptacles, Cables, and Pinouts” on page 19.)



**Caution** Before you attach an MII transceiver to an MII receptacle on your FEIP2, ensure that your MII transceiver responds to physical sublayer (PHY) address 0 per section 22.2.4.4. “PHY Address” of the IEEE 802.3u specification; otherwise, interface problems might result. Confirm that this capability is available on your MII transceiver with the transceiver's vendor or in the transceiver's documentation. If a selection for “Isolation Mode” is available, we recommend you use this setting (if no mention is made of “PHY addressing”).



**Caution** To prevent system problems, do not simultaneously connect cables to the RJ-45 (or SC) and MII receptacles on a single FEIP2, FE interface. Each FE interface (100BASE-FX or 100BASE-TX) can have *either* an MII attachment or an RJ-45 (or SC) attachment, but not both. The MII and RJ-45 (or SC) receptacles represent two physical connection options for one FE interface.

- Number 1 Phillips and a 3/16-inch, flat-blade screwdriver
- ESD-prevention equipment or disposable grounding wrist strap included with all Cisco products

### Safety Guidelines

Following are safety guidelines that you should follow when working with any equipment that connects to electrical power or telephone wiring.

### Safety Warnings

Safety warnings appear throughout this publication in procedures that, if performed incorrectly, may harm you. A warning symbol precedes each warning statement.



**Warning** This warning symbol means *danger*. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents. To see translations of the warnings that appear in this publication, refer to the *Regulatory Compliance and Safety Information* document that accompanied this device.

**Waarschuwing** Dit waarschuwingssymbool betekent gevaar. U verkeert in een situatie die lichamelijk letsel kan veroorzaken. Voordat u aan enige apparatuur gaat werken, dient u zich bewust te zijn van de bij elektrische schakelingen betrokken risico's en dient u op de hoogte te zijn van standaard maatregelen om ongelukken te voorkomen. Voor vertalingen van de waarschuwingen die in deze publicatie verschijnen, kunt u het document *Regulatory Compliance and Safety Information* (Informatie over naleving van veiligheids- en andere voorschriften) raadplegen dat bij dit toestel is ingesloten.

**Varoitus** Tämä varoitusmerkki merkitsee vaaraa. Olet tilanteessa, joka voi johtaa ruumiinvammaan. Ennen kuin työskentelet minkään laitteiston parissa, ota selvää sähkökytkentöihin liittyvistä vaaroista ja tavanomaisista onnettomuuksien ehkäisykeinoista. Tässä julkaisussa esiintyvien varoitusten käännökset löydät laitteen mukana olevasta *Regulatory Compliance and Safety Information* -kirjasesta (määräysten noudattaminen ja tietoa turvallisuudesta).

**Attention** Ce symbole d'avertissement indique un danger. Vous vous trouvez dans une situation pouvant causer des blessures ou des dommages corporels. Avant de travailler sur un équipement, soyez conscient des dangers posés par les circuits électriques et familiarisez-vous avec les procédures couramment utilisées pour éviter les accidents. Pour prendre connaissance des traductions d'avertissements figurant dans cette publication, consultez le document *Regulatory Compliance and Safety Information* (Conformité aux règlements et consignes de sécurité) qui accompagne cet appareil.

**Warnung** Dieses Warnsymbol bedeutet Gefahr. Sie befinden sich in einer Situation, die zu einer Körperverletzung führen könnte. Bevor Sie mit der Arbeit an irgendeinem Gerät beginnen, seien Sie sich der mit elektrischen Stromkreisen verbundenen Gefahren und der Standardpraktiken zur Vermeidung von Unfällen bewußt. Übersetzungen der in dieser Veröffentlichung enthaltenen Warnhinweise finden Sie im Dokument *Regulatory Compliance and Safety Information* (Informationen zu behördlichen Vorschriften und Sicherheit), das zusammen mit diesem Gerät geliefert wurde.

**Avvertenza** Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe causare infortuni alle persone. Prima di lavorare su qualsiasi apparecchiatura, occorre conoscere i pericoli relativi ai circuiti elettrici ed essere al corrente delle pratiche standard per la prevenzione di incidenti. La traduzione delle avvertenze riportate in questa pubblicazione si trova nel documento *Regulatory Compliance and Safety Information* (Conformità alle norme e informazioni sulla sicurezza) che accompagna questo dispositivo.

**Advarsel** Dette varselsymbolet betyr fare. Du befinner deg i en situasjon som kan føre til personskade. Før du utfører arbeid på utstyr, må du være oppmerksom på de faremomentene som elektriske kretser innebærer, samt gjøre deg kjent med vanlig praksis når det gjelder å unngå ulykker. Hvis du vil se oversettelser av de advarslene som finnes i denne publikasjonen, kan du se i dokumentet *Regulatory Compliance and Safety Information* (Overholdelse av forskrifter og sikkerhetsinformasjon) som ble levert med denne enheten.

**Aviso** Este símbolo de aviso indica perigo. Encontra-se numa situação que lhe poderá causar danos físicos. Antes de começar a trabalhar com qualquer equipamento, familiarize-se com os perigos relacionados com circuitos eléctricos, e com quaisquer práticas comuns que possam prevenir possíveis acidentes. Para ver as traduções dos avisos que constam desta publicação, consulte o documento *Regulatory Compliance and Safety Information* (Informação de Segurança e Disposições Reguladoras) que acompanha este dispositivo.

**¡Advertencia!** Este símbolo de aviso significa peligro. Existe riesgo para su integridad física. Antes de manipular cualquier equipo, considerar los riesgos que entraña la corriente eléctrica y familiarizarse con los procedimientos estándar de prevención de accidentes. Para ver una traducción de las advertencias que aparecen en esta publicación, consultar el documento titulado *Regulatory Compliance and Safety Information* (Información sobre seguridad y conformidad con las disposiciones reglamentarias) que se acompaña con este dispositivo.

**Varning!** Denna varningssymbol signalerar fara. Du befinner dig i en situation som kan leda till personskada. Innan du utför arbete på någon utrustning måste du vara medveten om farorna med elkretsar och känna till vanligt förfarande för att förebygga skador. Se förklaringar av de varningar som förekommer i denna publikation i dokumentet *Regulatory Compliance and Safety Information* (Efterrättelse av föreskrifter och säkerhetsinformation), vilket medföljer denna anordning.

### Electrical Equipment Guidelines

Follow these basic guidelines when working with any electrical equipment:

- Before beginning any procedures requiring access to the chassis interior, locate the emergency power-off switch for the room in which you are working.
- Disconnect all power and external cables before moving a chassis
- Do not work alone when potentially hazardous conditions exist.
- Never assume that power has been disconnected from a circuit; always check.
- Do not perform any action that creates a potential hazard or makes the equipment unsafe.
- Carefully examine your work area for possible hazards such as moist floors, ungrounded power extension cables, and missing safety grounds.

### Telephone Wiring Guidelines

Use the following guidelines when working with any equipment that is connected to telephone wiring or to other network cabling:

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

### Preventing Electrostatic Discharge Damage

Electrostatic discharge (ESD) damage, which can occur when electronic cards or components are improperly handled, results in complete or intermittent failures.

Use the following guidelines for preventing ESD damage:

- Always use an ESD wrist or ankle strap and ensure that it makes good skin contact.
- Connect the equipment end of the strap to an unfinished chassis surface.
- When installing a component, use any available ejector levers or captive installation screws to properly seat the bus connectors in the backplane.
- When removing a component, use any available ejector levers or captive installation screws to release the bus connectors from the backplane or midplane.
- Handle carriers by available handles or edges only; avoid touching the printed circuit boards or connectors.
- Place a removed component board-side-up on an antistatic surface or in a static shielding container; otherwise, immediately place it in a static shielding container.
- Avoid contact between the printed circuit boards and clothing. The wrist strap only protects components from ESD voltages on the body; ESD voltages on clothing can still cause damage.
- Never attempt to remove the printed circuit board from the metal carrier.



**Caution** For safety, periodically check the resistance value of the antistatic strap. The measurement should be between 1 and 10 megohms.

## Guidelines for Interface Processor Installation and Removal

This section describes mechanical functions of system components, emphasizes the importance of following correct procedures to avoid unnecessary board failures, and is for background only; specific procedures follow in the section “FEIP2 Installation” on page 23.

You can remove and replace interface processors while the system is operating; you do not need to notify the software or reset the system power. This functionality enables you to add, remove, or replace interface processors with the system online, which provides a method that is seamless to end users on the network, maintains all routing information, and ensures session preservation.

After an interface processor is reinstalled, the system brings on line only interfaces that match the current configuration and were previously configured as up; all others require that you configure them with the **configure** command.




**Caution** The system can indicate a hardware failure if you do not follow proper procedures. Remove or insert only one interface processor at a time. Allow at least 15 seconds for the system to complete the preceding tasks before removing or inserting another interface processor. Disrupting the sequence before the system completes its verification can cause the system to interpret hardware failures.

Cisco 7000 series and Cisco 7500 series routers have ejector levers located on the ends of the interface processor slots. (See Figure 1a.) The function of the ejector levers is to align and seat the card connectors in the backplane. Failure to use the ejector levers and insert the interface processor properly can disrupt the order in which the pins make contact with the card or interface processor. Follow the FEIP2 installation and removal instructions carefully, and review the following examples of *incorrect* insertion practices and their results:

- Using the handle to force the interface processor all the way into the slot can pop the ejector levers out of their springs. If you then try to use the ejector levers to seat the interface processor, the first layer of pins (which are already mated to the card or interface processor) can disconnect and then remate with the backplane, which the system interprets as a board failure.
- Using the handle to force or slam the interface processor all the way into the slot can damage the pins on the board connectors if they are not aligned properly with the backplane.
- When using the handle (rather than the ejector levers) to seat the interface processor in the backplane, you might need to pull the interface processor back out and push it in again to align it properly. Even if the backplane pins are not damaged, the pins mating with and disconnecting from the card or interface processor might cause the system to interpret a board failure. Using the ejector levers ensures that the board connector mates with the backplane in one continuous movement.
- Using the handle to insert or remove an interface processor, or failing to push the ejector levers fully against the interface processor, can leave some (not all) of the connector pins mated to the card or interface processor, a state which hangs the system. Using the ejector levers and making sure that they are pushed fully into position ensures that all three layers of pins are mated with (or free from) the backplane.

Use the ejector levers when removing an interface processor to ensure that the backplane connector pins disconnect from the interface processor in the sequence expected by the system. Any interface processor that is only partially connected to the backplane can hang the bus. Steps for correctly performing OIR are included with the following procedures for installing and removing the FEIP2.

Figure 1 Ejector Levers/Captive Installation Screws on the FEIP2 (Horizontal Orientation Shown)



**Note** The FEIP2 is oriented horizontally in the Cisco 7010 and Cisco 7505 and vertically in the Cisco 7000, Cisco 7507, and Cisco 7513.



## Microcode Overview

The FEIP2 microcode (firmware) is an image that provides card-specific software instructions. A programmable read-only memory (PROM) device on the FEIP2 contains a default microcode boot image that assists the system in finding and loading the microcode image from the Cisco IOS software bundle or Flash memory. The router supports downloadable microcode, which allows you to upgrade microcode versions by downloading new microcode images, storing them in system Flash memory, and instructing the system to load its image from Flash. You can store multiple images for an interface type and, with a configuration command, instruct the system to load any one of them or the default microcode image. The microcode boot image in the PROM initializes the FEIP2 and then assists downloading the FEIP2 microcode image. All interfaces of the same type (FEIP2, and so on) load the same microcode image, either from the microcode image bundled with the Cisco IOS software or from an image stored in system Flash. Although multiple microcode versions for a specific interface type can be stored concurrently in Flash, only one image can load at startup.

The **show controllers cbus** command displays the currently loaded and running microcode version for each interface processor, and FEIP2. The **show startup-config EXEC** command shows the current system instructions for loading microcode at startup.

Software and interface processor microcode images are carefully optimized and bundled to work together. Overriding the bundle can result in system incompatibilities. We recommend that you use the microcode included in the software bundle. For a complete description of microcode and downloading procedures, refer to the section “Upgrading FEIP2 Microcode” on page 39.

## Fast Ethernet Overview

The term *Ethernet* is commonly used for all carrier sense multiple access/collision detection (CSMA/CD), local-area networks (LANs) that generally conform to Ethernet specifications, including Fast Ethernet under IEEE 802.3u.

---

**Note** 100BASE-TX is intended for Environment A, and 100BASE-FX is intended for Environment B.

---

IEEE 802.3u is well suited to applications where a local communication medium must carry sporadic, occasionally heavy traffic at high peak data rates. Stations on a CSMA/CD LAN can access the network at any time. Before sending data, the station *listens* to the network to see if it is already in use. If it is, the station waits until the network is not in use, then transmits; this is half-duplex operation.

A collision occurs when two stations listen for network traffic, hear none, and transmit very close to simultaneously. When this happens, both transmissions are damaged, and the stations must retransmit. The stations detect the collision and use backoff algorithms to determine when they should retransmit. Both Ethernet and IEEE 802.3u are broadcast networks, which means that all stations see all transmissions. Each station must examine received frames to determine if it is the intended destination and, if it *is*, to pass the frame to a higher protocol layer for processing.

IEEE 802.3u specifies the following different physical layers for 100BASE-T:

- 100BASE-TX—100BASE-T, half and full duplex over Category 5 unshielded twisted-pair (UTP), Electronics Industry Association/Telecommunications Industry Association [EIA/TIA]–568-compliant cable
- 100BASE-FX—100BASE-T, half and full duplex over optical fiber
- 100BASE-T4—100BASE-T, half and full duplex over Category 3, 4, or 5 UTP or shielded twisted-pair (STP) cabling with four pairs; also called *4T+* or *T2*, which is 2-pair UTP over Category 3 cable.

Each physical layer protocol has a name that summarizes its characteristics in the format speed/signaling method/segment length, where speed is the LAN speed in megabits per second (Mbps), signaling method is the signaling method used (either baseband or broadband), and segment length is typically the maximum length between stations in hundreds of meters. Therefore, 100BASE-T specifies a 100-Mbps, baseband LAN with maximum network segments of 100 meters (or 400 meters for 100BASE-FX).

## IEEE 802.3u 100BASE-T Specifications

Table 2 lists the cabling specifications for 100-Mbps Fast Ethernet transmission over UTP, STP, and fiber-optic cables. Table 3 summarizes IEEE 802.3u 100BASE-T physical characteristics for 100BASE-TX and 100BASE-FX.

**Table 2 Specifications and Connection Limits for 100-Mbps Transmission**

Parameter	RJ-45	MII	SC-Type
Cable specification	Category 5 <sup>1</sup> UTP <sup>2</sup> , 22 to 24 AWG <sup>3</sup>	Category 3, 4, or 5, 150-ohm UTP or STP, or multimode optical fiber	62.5/125 multimode optical fiber
Maximum cable length	–	1.64 ft (0.5 m) (MII-to-MII cable <sup>4</sup> )	–
Maximum segment length	328 ft (100 m) for 100BASE-TX	3.28 ft (1 m) <sup>5</sup> or 1,312 ft (400 m) for 100BASE-FX	328 ft (100 m)
Maximum network length	656 ft (200 m) <sup>5</sup> (with 1 repeater)	–	656 ft (200 m) <sup>5</sup> (with 1 repeater)

1. EIA/TIA-568 or EIA-TIA-568 TSB-36 compliant.

2. Cisco Systems does not supply Category 5 UTP RJ-45 or 150-ohm STP MII cables. Both are available commercially.

3. AWG = American Wire Gauge. This gauge is specified by the EIA/TIA-568 standard.

4. This is the cable between the MII port on the FE interface and the appropriate transceiver.

5. This length is specifically between any two stations on a repeated segment.

**Table 3 IEEE 802.3u Physical Characteristics**

Parameter	100BASE-FX	100BASE-TX
Data rate (Mbps)	100	100
Signaling method	Baseband	Baseband
Maximum segment length (meters)	100 m between repeaters	100 m between DTE <sup>1</sup> and repeaters
Media	SC-type: dual simplex or single duplex for Rx and Tx	RJ-45MII
Topology	Star/hub	Star/hub

1. DTE = data terminal equipment.


## What Is the Cisco 7000 Series?

The Cisco 7000 series consists of the Cisco 7000 and Cisco 7010 routers. The FEIP2 operates in the Cisco 7000 series routers if these routers have the 7000 Series Route Switch Processor (RSP7000) and 7000 Series Chassis Interface (RSP7000CI) installed. (For software and hardware requirements, refer to the section “Software and Hardware Prerequisites” on page 3.)

Network interfaces reside on modular interface processors, including the FEIP2, which are inserted into interface processor slots and provide a direct connection between external networks and the high-speed CxBus in the Cisco 7000 series. The Cisco 7000 series supports any combination of available network interface types.


In the 7-slot Cisco 7000, slot 5 is reserved for the RSP7000 (7000 RSP slot shown in Figure 2), which contains the system processor and performs packet switching functions, and slot 6 is reserved for the RSP7000CI (7000 CI slot shown in Figure 2), which contains all of the environmental monitoring functions for the Cisco 7000. The remaining five slots (slots 0 through 4) are for interface processors including the FEIP2.

**Figure 2 Cisco 7000 with RSP7000 and RSP7000CI Installed (Interface Processor End)**



In the 5-slot Cisco 7010, slot 3 is reserved for the RSP7000, which contains the system processor and performs packet switching functions, and slot 4 is reserved for the RSP7000CI, which contains all of the environmental monitoring functions for the Cisco 7010. The remaining three slots (slots 0 through 2) are for interface processors including the FEIP2.

**Figure 3 Cisco 7010 with RSP7000 and RSP7000CI Installed (Interface Processor End)**



## What Is the Cisco 7500 Series?

The Cisco 7500 series includes the Cisco 7505, Cisco 7507, and Cisco 7513 routers. The FEIP2 operates in the Cisco 7500 series routers. (For software and hardware requirements, refer to the section “Software and Hardware Prerequisites” on page 3.)

Network interfaces reside on modular interface processors, including the FEIP2, which are inserted into interface processor slots and provide a direct connection between external networks and the high-speed CyBus in the Cisco 7500 series. The Cisco 7500 series supports any combination of available network interface types.

Figure 4 shows the interface processor end of the Cisco 7505. In the 5-slot Cisco 7505, one slot (4) is reserved for the Route Switch Processor (RSP1 or RSP4), which contains the system processor and performs packet switching functions. Slots 0 through 3 are for interface processors including the FEIP2.

**Figure 4 Cisco 7505 (Interface Processor End)**




Figure 5 shows the interface processor end of the Cisco 7507 router. In the 7-slot Cisco 7507, up to two slots (2 and 3) are reserved for the Route Switch Processor (RSP2 or RSP4), which contains the system processor and performs packet switching functions. Slots 0 and 1 and 4 through 6 are for interface processors including the FEIP2.

Figure 5 Cisco 7507 (Interface Processor End)





Figure 6 shows the interface processor end of the Cisco 7513 router. In the Cisco 7513, up to two slots (6 and 7) are reserved for the second generation Route Switch Processor (RSP2 or RSP4), which contains the system processor and performs packet switching functions. Slots 0 through 5 and 8 through 12 are for interface processors including the FEIP2.

**Figure 6 Cisco 7513 (Interface Processor End)**




## What Is the FEIP2?

The FEIP2 is a dual-port, fixed configuration interface processor that provides two, 100-Mbps, IEEE 802.3u Fast Ethernet (FE) interface interfaces.

The FEIP2 is available in the following fixed configurations:

- FEIP2-2TX(=)—FEIP2 with two, 100BASE-TX FE interfaces (See Figure 7.)

**Figure 7 Fast Ethernet Interface Processor (FEIP2-2TX)**




Each 100BASE-TX interface on the FEIP2-2TX has an RJ-45 connector to attach to Category 5 unshielded twisted-pair (UTP) for 100BASE-TX, and an MII connector that permits connection through external transceivers to multimode fiber for 100BASE-FX, or to Category 3, 4, and 5 UTP or shielded twisted-pair (STP) for 100BASE-T4 physical media.

Each FE interface on an FEIP2 can be configured at 100 Mbps, half duplex, for a maximum aggregate bandwidth of 200 Mbps per pair. Each FE interface on an FEIP2 can also be configured at 200 Mbps, full duplex, for a maximum aggregate bandwidth of 400 Mbps per pair. Further, one FE interface can be configured at 100 Mbps, half duplex, while the other FE interface can be configured at 200 Mbps, full duplex, for a maximum aggregate bandwidth of 300 Mbps per pair.



- FEIP2-2FX(=)—FEIP2 with two, 100BASE-FX FE interfaces (See Figure 8.)

**Figure 8 Fast Ethernet Interface Processor (FEIP2-2FX)**



Each 100BASE-FX interface on the FEIP2-2FX has an SC-type fiber-optic connector for 100BASE-FX, and an MII connector that permits connection through external transceivers to multimode fiber for 100BASE-FX, or to Category 3, 4, and 5 UTP or shielded twisted-pair (STP) for 100BASE-T4 physical media.

For pinouts, refer to the section “FEIP2 Receptacles, Cables, and Pinouts” on page 19. The standard dynamic random access memory (DRAM) size for the FEIP2 is 8 megabytes (MB), and the standard static random access memory (SRAM) size for the FEIP2 is 1 MB. You can install FEIP2s in any available interface processor slots.

---

**Note** Each FEIP2 model is a fixed configuration; therefore, individual FE interfaces are not available as spare parts, do not have handles, and are not field replaceable or removable. The entire FEIP2 assembly must be treated as a field-replaceable unit (FRU).

---



**Caution** To prevent system problems, we recommend that you not attempt to remove an FEIP2’s FE interface and replace it with another, nor attempt to mix 100BASE-TX and 100BASE-FX FE interfaces on the same FEIP2.

---

**Note** Each of the FEIP2-2FX's two 100BASE-FX interfaces uses the MII connector like the FEIP2-2TX, but the FEIP2-2FX has an SC-type fiber-optic connector in place of the RJ-45 connector. Either the MII LED *or* the RJ-45 (or FIBER) LED should be on at any one time; never both.

---




**Caution** To prevent system problems, do not simultaneously connect cables to the RJ-45 (or SC) and MII receptacles on a single FEIP2 FE interface. Each FE interface (100BASE-FX or 100BASE-TX) can have *either* an MII attachment or an RJ-45 (or SC) attachment, but not both. The MII and RJ-45 (or SC) receptacles represent two physical connection options for one FE interface.

## FEIP2 LEDs

The FEIP2 contains the enabled LED and a bank of three status LEDs for each of the two FE interfaces (located between the two receptacles on each FE interface). After system initialization, the enabled LED goes on to indicate that the FEIP2 has been enabled for operation. (The LEDs are shown in Figure 9.)

**Figure 9 LEDs on a Fast Ethernet Interface (Partial Faceplate View of FEIP2-2TX)**



The following conditions must be met before the enabled LED goes on:

- The FEIP2 is correctly connected and receiving power
- The FEIP2 card contains a valid microcode version that has been downloaded successfully
- The bus recognizes the FEIP2.

If any of these conditions is not met, or if the initialization fails for other reasons, the enabled LED does not go on.

Following are the three status LEDs and an explanation of what each indicates:

- **MII**—On when the MII port is selected as the active port by the controller.
- **Link**—When the RJ-45 or SC port is active, this LED is on when the FE interface is receiving a carrier signal from the network. When the MII port is active, this LED is an indication of network activity, and it flickers on and off proportionally to this activity.
- **RJ45 (or FIBER on FEIP2-2FX)**—On when the RJ-45 (or FIBER) port is selected as the active port by the controller.

## FEIP2 Receptacles, Cables, and Pinouts


The two interface receptacles on each Fast Ethernet interface are a single MII, 40-pin, D-shell type receptacle, and a single RJ-45 receptacle (or SC-type for FEIP2-2FX optical-fiber connections). (See the FEIP2-2TX in Figure 10 and the FEIP2-2FX in Figure 11.)

You can use either one receptacle or the other; only one receptacle can be used at one time. Each connection supports IEEE 802.3u interfaces compliant with the 100BASE-X and 100BASE-T standards. The RJ-45 connection does not require an external transceiver. The MII connection requires an external physical sublayer (PHY) and an external transceiver. Cisco Systems does not supply Category 5 UTP RJ-45 cables; these cables are available commercially.




**Caution** To prevent system problems, do not simultaneously connect cables to the RJ-45 (or SC) and MII receptacles on a single FEIP2, FE interface. Each FE interface (100BASE-FX or 100BASE-TX) can have *either* an MII attachment or an RJ-45 (or SC) attachment, but not both. The MII and RJ-45 (or SC) receptacles represent two physical connection options for one FE interface.

**Figure 10 Single FEIP2-2TX Fast Ethernet Interface (Faceplate View)**




**Figure 11 Single FEIP2-2FX Fast Ethernet Interface (Faceplate View)**



The RJ-45 connection does not require an external transceiver. The MII connection requires an external physical sublayer (PHY) and an external transceiver. Figure 12 shows the RJ-45 cable connectors. RJ-45 cables are not available from Cisco Systems, but are available from commercial cable vendors. Table 4 lists the pinouts and signals for the RJ-45 connectors.

**Figure 12 RJ-45 Connections, Plug and Receptacle (FEIP2-2TX)**





**Warning** The ports labeled “Ethernet,” “10BaseT,” “Token Ring,” “Console,” and “AUX” are safety extra-low voltage (SELV) circuits. SELV circuits should only be connected to other SELV circuits. Because the BRI circuits are treated like telephone-network voltage, avoid connecting the SELV circuit to the telephone network voltage (TNV) circuits.

Table 4 lists the pinouts and signals for the FEIP2-2TX’s RJ-45 connectors.


**Table 4 RJ-45 Connector Pinout (FEIP2-2TX)**

Pin	Description
1	Receive Data + (RxD+)
2	RxD–
3	Transmit Data + (TxD+)
6	TxD–

**Note** Referring to the RJ-45 pinout in Table 4, proper common-mode line terminations should be used for the unused Category 5, UTP cable pairs 4/5 and 7/8. Common-mode termination reduces the contributions to electromagnetic interference (EMI) and susceptibility to common-mode sources. Wire pairs 4/5 and 7/8 are actively terminated in the RJ-45, 100BASE-TX port circuitry in the FEIP2-2TX.

Depending on your RJ-45 interface cabling requirements, use the pinouts in Figure 13 and Figure 14.

**Figure 13 Straight-Through Cable Pinout, RJ-45 Connection to a Hub or Repeater (FEIP2-2TX)**



**Figure 14 Crossover Cable Pinout, RJ-45 Connections Between Hubs and Repeaters (FEIP2-2TX)**






Figure 15 shows the duplex SC connector (one required for both transmit and receive), and Figure 16 shows the simplex SC connector (two required, one for each transmit and receive) used for 100BASE-FX optical-fiber connections on the FEIP2-2FX. These multimode, SC-type, optical-fiber cables are commercially available; they are not available from Cisco Systems.

**Figure 15 Duplex SC Connector (FEIP2-2FX)**



**Figure 16 Simplex SC Connector (FEIP2-FX)**



Depending on the type of media you use between the MII connection on the FE interface and your switch or hub, the network side of your 100BASE-T transceiver should be appropriately equipped with ST-type connectors (for optical fiber), BNC connectors, and so forth. Figure 17 shows the pin orientation of the female MII connector on the FE interface.

The MII receptacle (on both the FEIP2-2FX and FEIP2-2TX) uses 2-56 screw-type locks, called *jack screws* (shown in Figure 17), to secure the cable or transceiver to the MII port. MII cables and transceivers have knurled thumbscrews (screws you can tighten with your fingers) that you fasten to the jack screws on the FEIP2's MII connector. Use the jack screws to provide strain relief for your MII cable. (The RJ-45 modular plug has strain relief functionality incorporated into the design of its standard plastic connector.) Figure 17 shows the MII female connector.

**Figure 17 MII Connection, Receptacle (FEIP2-2FX and FEIP2-2TX)**




Table 5 lists the MII connector pinout and signals. MII cables are available commercially; they are not available from Cisco Systems. Table 5 refers to MII cables used between the MII connector on the FEIP2 and an appropriate transceiver. The connection between this transceiver and your network can be Category 3, 4, or 5, 150-ohm UTP or STP, or multimode optical fiber.

**Table 5 MII Connector Pinout (FEIP2-2FX and FEIP2-2TX)**

Pin <sup>1</sup>	In	Out	In/Out	Description
14–17	–	Yes	–	Transmit Data (TxD)
12	Yes	–	–	Transmit Clock (Tx_CLK) <sup>2</sup>
11	–	Yes	–	Transmit Error (Tx_ER)
13	–	Yes	–	Transmit Enable (Tx_EN)
3	–	Yes	–	MII Data Clock (MDC)
4–7	Yes	–	–	Receive Data (RxD)
9	Yes	–	–	Receive Clock (Rx_CLK)
10	Yes	–	–	Receive Error (Rx_ER)
8	Yes	–	–	Receive Data Valid (Rx_DV)
18	Yes	–	–	Collision (COL)
19	Yes	–	–	Carrier Sense (CRS)
2	–	–	Yes	MII Data Input/Output (MDIO)
22–39	–	–	–	Common (ground)
1, 20, 21, 40	–	–	–	+5.0 volts (V)

1. Any pins not indicated are not used.

2. Tx\_CLK and Rx\_CLK are generated by the external transceiver.

## FEIP2 Installation

The following sections describe the procedures for removing or installing an FEIP2 in the Cisco 7000 series or Cisco 7500 series routers. The functionality is the same for each router model; therefore, the term *the chassis* is used except where specific model issues arise.

The online insertion and removal function allows you to install and remove an FEIP2 without first shutting down the system; however, you must follow the instructions carefully. Failure to insert the FEIP2 properly can cause system error messages indicating a board failure. For a complete description of recommended guidelines for interface processor installation and removal, refer to the section “Guidelines for Interface Processor Installation and Removal” on page 7.

Each unused interface processor slot must contain an interface processor filler (which is an interface processor carrier without an interface board) to keep dust out of the chassis and to maintain proper air flow through the interface processor compartment. If you are installing a new FEIP2 that is not a replacement, you must first remove the interface processor filler from an unused slot; to do so proceed to the next section “Removing an Interface Processor or Interface Processor Filler.” If you are replacing an FEIP2, proceed to the section “Removing an FEIP2.”

---

**Note** To ensure compliance with EMI approvals by providing a tight EMI-preventive seal for the Cisco 7507 and Cisco 7513 routers, we recommend that you first install interface processors in the interface processor slots closest to the RSP slots, whenever possible, then work out to the interface processor slots furthest from the RSP slots. (See Figure 5, on page 14, for the Cisco 7507; see Figure 6, on page 15, for the Cisco 7513.)

---

### Removing an Interface Processor or Interface Processor Filler

If you plan to replace a currently installed interface processor with an FEIP2, attach an ESD-preventive wrist strap between you and any unpainted chassis surface; interface processor fillers do not require protection from ESD. Select an interface processor slot for the new FEIP2 and remove the interface processor or interface processor filler as follows:

- Step 1** Use a screwdriver to loosen the captive installation screws on the interface processor or interface processor filler. (See Figure 1.)
- Step 2** Place your thumbs on both ejector levers and simultaneously pull them both outward to release the filler from the backplane connector (in the opposite direction from that shown in Figure 1c).
- Step 3** Grasp the handle with one hand and pull the card straight out of the slot, keeping your other hand under the carrier to guide it. (See Figure 18.) Keep the carrier parallel to the backplane.
- Step 4** Store the interface processor or interface processor filler for future use.

To help prevent dust and contaminants from entering the chassis, do not leave the interface processor slot open. Immediately proceed to the section “Installing an FEIP2” on page 25.

## Removing an FEIP2

You need not shut down the interface or the system power when removing an FEIP2 or interface processor.

---

**Note** In Cisco 7507 or Cisco 7513 systems, online insertion and removal of any interface processor in either CyBus might cause the slave RSP2 to reboot with a bus error or a processor memory parity error. The master RSP will recover from this event and issue a “cBus Complex Restart” message. Cisco 7507 and Cisco 7513 systems that are configured with an RSP4 as the system slave are not affected and will not experience this problem.

---


If you have a Cisco 7507 or a Cisco 7513 with an RSP2 configured as the system slave, we strongly recommend that you use the following procedure to remove and replace an interface processor:

- Step 1** Remove the slave RSP2.
- Step 2** Wait 15 seconds.
- Step 3** Remove and replace the interface processor using the procedures in this publication.
- Step 4** Wait 15 seconds.
- Step 5** Reinsert the slave RSP2.

If you are replacing a failed FEIP2, remove the existing board first, then install the new FEIP2 in the same slot. If you are replacing a currently installed interface processor with an FEIP2, remove the existing board first, then install the new FEIP2 in the same slot.

Figure 18 shows proper handling of an interface processor during installation.

**Figure 18 Handling Processor Modules for Installation and Removal (Horizontal Orientation Shown)**





To remove an FEIP2 or interface processor, follow these steps:

- Step 1** Attach an ESD-preventive wrist strap between you and any unpainted chassis surface.
- Step 2** If you are replacing a failed FEIP2, disconnect all cables from the FEIP2 ports; however, if you are only moving an FEIP2 to another slot, this step is not necessary.
- Step 3** Use a screwdriver to loosen the captive installation screws at both ends of the board. (See Figure 1.)



**Caution** Always use the ejector levers to remove or install the FEIP2. Failure to do so can cause erroneous system error messages indicating a board failure.

- Step 4** Place your thumbs on the ejector levers and simultaneously pull both of the ejectors outward (in the opposite direction from that show in Figure 1c) to release the FEIP2 from the backplane connector.
- Step 5** Use the board's handle to carefully pull it straight out of the slot, keeping your other hand under the carrier to guide it. (See Figure 18.) Keep the board parallel to the backplane.
- Step 6** Place the removed board on an antistatic mat or foam pad, or place it in an antistatic container if you plan to return it to the factory.
- Step 7** If the interface processor slot is to remain empty, install a filler (MAS7K-BLANK) to keep dust out of the chassis and to maintain proper air flow inside the chassis. *Do not* leave the interface processor slot open. Immediately proceed to the section "Installing an FEIP2."

## Installing an FEIP2

The FEIP2 slides into the open interface processor slot and connects directly to the backplane. The interface processors are keyed to guide pins on the backplane, so the FEIP2 can be installed only in an interface processor slot.

---

**Note** To ensure compliance with EMI approvals, by providing a tight EMI seal for the Cisco 7507 and Cisco 7513 routers, we recommend that you first install interface processors in the interface processor slots closest to the RSP slots, whenever possible, then work out to the interface processor slots furthest from the RSP slots.

---

Figure 1 shows the functional details of inserting an interface processor and using the ejector levers. Figure 18 shows proper handling of an interface processor during installation.



**Caution** Remove or insert only one interface processor at a time. Allow at least 15 seconds for the system to complete its discovery and initialization before removing or inserting another interface processor. Disrupting the sequence before the system has completed verification can cause the system to interpret hardware failures.

Follow these steps to install an FEIP2:

- Step 1** Ensure that a console terminal is connected to the console port (on the RSP or RSP7000) and that your console is turned ON.
- Step 2** Hold the FEIP2 handle with one hand and place your other hand under the carrier to support the FEIP2 and guide it into the slot. (See Figure 18.) Avoid touching the card or any connector pins.



**Caution** To prevent ESD damage, handle interface processors by the handles and carrier edges only.

---

**Note** The processor modules are oriented horizontally in the Cisco 7010 and Cisco 7505 and vertically in the Cisco 7000, Cisco 7507, and the Cisco 7513.

---

- Step 3** Place the back of the FEIP2 in the slot and align the notch on the carrier with the groove in the slot. (See Figure 1.)
- Step 4** While keeping the FEIP2 parallel to the backplane, carefully slide it into the slot until the back of the faceplate makes contact with the ejector levers, then *stop*. (See Figure 1b.)



**Caution** Always use the ejector levers when installing or removing processor modules. A module that is partially seated in the backplane might cause the system to hang and subsequently crash, and shoving or slamming the interface processor into the slot can damage the backplane pins and board.

- Step 5** Using your thumbs, simultaneously push both ejector levers inward until the FEIP2 is pushed entirely into its slot. (See Figure 1c.)
- Step 6** Tighten both of the captive installation screws.



**Caution** To ensure proper electromagnetic interference (EMI) isolation for the chassis, make certain to tighten the captive installation screws on each FEIP2 immediately after you install it and *before* proceeding with the installation of each remaining FEIP2 or other interface processor.

## Attaching Fast Ethernet Interface Cables

The MII and RJ-45 (or SC) receptacles represent two physical connection options for one FE interface. Each FEIP2 has two FE interfaces. On a single FE interface, you can use *either* the RJ-45 (or SC for FEIP2-2FX) connection *or* the MII connection. You can use the RJ-45 (or SC for FEIP2-2FX) connection on one FE interface and the MII connection on the other.

---

**Note** RJ-45, SC, and MII cables are not available from Cisco Systems; they are available from outside commercial cable vendors.

---

Connect RJ-45, SC (FEIP2-2FX), or MII cables as follows:

**Step 1** If you have MII connections, attach an MII cable directly to the MII port on the FEIP2 or attach a 100BASE-T transceiver, with the media appropriate to your application, to the MII port on the FEIP2. (See Figure 19 for FEIP2-2TX or Figure 20 for FEIP2-2FX.)




**Caution** Before you attach an MII transceiver to an MII receptacle on your FEIP2, ensure that your MII transceiver responds to physical sublayer (PHY) address 0 per section 22.2.4.4. “PHY Address” of the IEEE 802.3u specification; otherwise, interface problems might result. Confirm that this capability is available on your MII transceiver with the transceiver's vendor or in the transceiver's documentation. If a selection for “Isolation Mode” is available, we recommend you use this setting (if no mention is made of “PHY addressing”).


If you have RJ-45 connections, attach the Category 5 UTP cable directly to one of the RJ-45 ports on the FEIP2. (See Figure 19 for FEIP2-2TX or Figure 20 for FEIP2-2FX.) The FEIP2 is an end station device and not a repeater. You *must* connect the FE interface to a repeater or hub.

If you have an SC connection (FEIP2-2FX), attach a cable directly to the SC port on one of the FEIP2-2FX's interfaces. (See Figure 20.) Use either one duplex SC connector, or two simplex SC connectors, and observe the correct relationship between the receive (RX) and transmit (TX) ports on the FEIP2-2FX and your repeater.

**Figure 19 Connecting MII or RJ-45 Cables (FEIP2-2TX Shown, Horizontal Orientation)**




**Note** Each Fast Ethernet interface (100BASE-FX or 100BASE-TX) can have *either* an MII attachment or an RJ-45 (or SC) attachment, but not both. The MII and RJ-45 (or SC) receptacles represent two physical connection options for one FE interface.

**Figure 20 Connecting MII or SC Cables (FEIP2-2FX Shown, Horizontal Orientation)**

**Step 2** For the 100BASE-TX RJ-45 connections, attach the ferrite bead to the RJ-45 cable (at either end), as shown in Figure 21.



**Caution** The ferrite bead prevents electromagnetic interference (EMI) from affecting the 100BASE-TX-equipped system and is a required component for proper system operation.

**Figure 21 Attaching the Ferrite Bead around the RJ-45 Cable**

**Caution** To prevent problems on your FEIP2 and network, do not simultaneously connect RJ-45 (or SC) and MII cables to one FE interface. On a single FE interface, only one network connection can be used at one time. Only connect cables that comply with EIA/TIA-568 standards. (Refer to Table 2 and Table 3, on page 10, for cable recommendations and specifications.)

**Step 3** Attach the network end of your RJ-45 (or SC) or MII cable to your 100BASE-T transceiver, switch, hub, repeater, DTE, or other external 100BASE-T equipment.


**Step 4** Repeat Steps 1 through 3 for the second FE interface as required.

This completes the FEIP2 cable installation.

## Using LEDs to Check FEIP2 Status

The FEIP2 has four status LEDs on its faceplate that indicate status on each FE port. (See Figure 22.)

**Figure 22 LEDs (Partial Faceplate View of FEIP2)**



After you connect cables, observe the LED states and the console display as the router initializes. When the system has reinitialized all interfaces, the enabled LED on the FEIP2 should go on. (For complete descriptions of the FEIP2 LEDs, refer to the section “FEIP2 LEDs” on page 18.)

The console screen will also display a message as the system discovers each interface during its reinitialization. After system initialization, the enabled LED goes on to indicate that the FEIP2 is enabled for operation.

The following conditions must be met before the FEIP2 is enabled:

- The interface processor is correctly connected to the backplane and receiving power.
- The system bus recognizes the interface processor.
- A valid version of microcode is loaded and running.

If any of these conditions is not met, the enabled LED does not go on.

Verify that the FEIP2 is connected correctly as follows:

- Step 1** While the system reinitializes each interface, observe the console display messages and verify that the system discovers the FEIP2. The system should recognize the FEIP2’s interfaces but leaves them configured as *down*.
- Step 2** When the reinitialization is complete, verify that the enabled LED on each FEIP2 FE interface is on and remains on. If the LED does stay on, proceed to Step 5. If the enabled LED does not stay on, proceed to the next step.
- Step 3** If an enabled LED fails to go on, suspect the that the FEIP2 board connector is not fully seated in the backplane. Loosen the captive installation screws, then firmly push the top ejector down while pushing the bottom ejector up until both are parallel to the FEIP2 faceplate. Tighten the captive installation screws. After the system reinitializes the interfaces, the enabled LED on the FEIP2 should go on. If the enabled LED goes on, proceed to Step 5. If the enabled LED does not go on, proceed to the next step.

- Step 4** If an enabled LED still fails to go on, remove the FEIP2 and try installing it in another available interface processor slot.
- If the enabled LED goes on when the FEIP2 is installed in the new slot, suspect a failed backplane port in the original interface processor slot.
- If the enabled LED still fails to go on, but other LEDs on the FEIP2 go on to indicate activity, proceed to Step 5 to resume the installation checkout and suspect that the enabled LED on the FEIP2 has failed.
- If no LEDs on the FEIP2 go on, suspect that the FEIP2 is faulty.
- If the enabled LED still does not go on, do not proceed with the installation. Contact a service representative to report the faulty equipment and obtain further instructions.
- Step 5** Use the **show interfaces** or **show controllers cbus** command to verify the status of the FEIP2's interfaces. (If the interfaces are not configured, you must configure them using the procedures in the section "Configuring the Fast Ethernet Interfaces.")

If an error message displays on the console terminal, refer to the appropriate reference publication for error message definitions. If you experience other problems that you are unable to solve, contact a service representative for assistance.

## Configuring the Fast Ethernet Interfaces

If you installed a new Fast Ethernet (FE) interface or if you want to change the configuration of an existing interface, you must enter configuration mode using the **configuration** command. If you replaced an interface that was previously configured, the system recognizes the new interface and bring it up in its existing configuration.

After you verify that the new FE interface is installed correctly (the enabled LED goes on), use the privileged-level **configure** command to configure the new interfaces. Be prepared with the information you need, such as the following:

- Protocols you plan to route on each new interface
- Internet protocol (IP) addresses if you plan to configure the interfaces for IP routing
- Whether the new interfaces will use bridging

For a summary of the configuration options available and instructions for configuring the FE interfaces on the FEIP2, refer to the appropriate configuration publications listed in the section "If You Need More Information" on page 2.

The **configure** command requires privileged-level access to the EXEC command interpreter, which usually requires a password. Contact your system administrator if necessary to obtain EXEC-level access.

---

**Note** Each FE interface on an FEIP2 can be configured at 100 Mbps, half duplex, for a maximum aggregate bandwidth of 200 Mbps per pair. Each FE interface on an FEIP2 can also be configured at 200 Mbps, full duplex, for a maximum aggregate bandwidth of 400 Mbps per pair. Further, one FE interface can be configured at 100 Mbps, half duplex, while the other FE interface can be configured at 200 Mbps, full duplex, for a maximum aggregate bandwidth of 300 Mbps per pair.

---

## Selecting Interface Processor Slot, Fast Ethernet Interface, and Interface Port Numbers

This section describes how to identify interface processor slot, FE interface, and interface port numbers.

---

**Note** Although the interface processor slots in the Cisco 7000, Cisco 7507, and Cisco 7513 are vertically oriented and those in the Cisco 7010 and Cisco 7505 are horizontally oriented, all models use the same method for slot and port numbering.

---

In the router, physical port addresses specify the actual physical location of each interface port on the router interface processor end. (See the example of an FEIP2-2TX shown in Figure 23.) This address is composed of a three-part number in the format *interface processor slot number/adaptor number/interface port number*.

- The first number identifies the chassis interface processor slot in which the FEIP2 is installed (as shown in the example system in Figure 23).
- The second number identifies the physical FE interface on the FEIP2 and is slot 0 (on the left) and slot 1 (on the right).
- The third number identifies the FE interface port, which is always numbered as interface 0.

Interface ports on the FEIP2 maintain the same address regardless of whether other interface processors are installed or removed. However, when you move an FEIP2 to a different slot, the first number in the address changes to reflect the new interface processor slot number.


Figure 23 shows the interface processor slots and interface ports of a sample Cisco 7505 system. On the FEIP2-2TX, the first FE interface number is 0 and the second is 1. For example, on the FEIP2 in slot 3 (shown in Figure 23), the address of the left (first) FE interface is 3/0/0 (interface processor slot 3, FE interface 0, and interface port 0). The address of the right (second) FE interface is 3/1/0 (interface processor slot 3, FE interface 1, and interface port 0).

---

**Note** If you remove the FEIP2-2TX from slot 3 and install it in interface processor slot 2, the addresses of these FE interfaces become 2/0/0 and 2/1/0.

---

**Figure 23 FE Interface Port Address Example (Cisco 7505 with FEIP2-2TX Shown)**



**Note:** The MII and RJ-45 interface ports on each port adapter are both numbered as interface port 0. Only one of them can be used on each port adapter, at one time.

You can identify interface ports by physically checking the slot/adapter/interface port location on the back of the router or by using software commands to display information about a specific interface or all interfaces in the router.

## Configuring Interfaces—Descriptions and Examples

This section describes a basic configuration. Press the **Return** key after each step unless otherwise noted. At any time you can exit the privileged level and return to the user level by entering **disable** at the prompt as follows:

```
Router# disable
```

```
Router>
```

Following is a basic configuration procedure:

**Step 1** At the privileged-level prompt, enter configuration mode and specify that the console terminal is the source of the configuration subcommands, as follows:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

**Step 2** At the prompt, specify the first interface to configure by entering the subcommand **interface**, followed by the *type (fastethernet)* and *slot/port* (interface processor slot number/0). The example that follows is for the interface port of the first FE interface port, on an FEIP2 in interface processor slot 1:

```
Router(config)# interface fa 1/0/0
```

**Step 3** If IP routing is enabled on the system, you can assign an IP address and subnet mask to the interface with the **ip address** configuration subcommand, as in the following example:

```
Router(config-int)# ip address 1.1.1.10 255.255.255.0
```



**Step 4** Add any additional configuration subcommands required to enable routing protocols and set the interface characteristics.

**Step 5** Change the shutdown state to up and enable the interface as follows:

```
Router(config-int)# no shutdown
```

**Step 6** Configure additional FE interfaces as required.

**Step 7** When you have included all of the configuration subcommands to complete the configuration, press **Ctrl-Z** to exit configuration mode.

**Step 8** Write the new configuration to nonvolatile memory as follows:

```
Router# copy running-config startup-config
[OK]
Router#
```

Following are descriptions and examples of the commands for configuring FE interface 3/0/0. Descriptions are limited to fields that are relevant for establishing and verifying the configuration. After configuring the new FE interface, use **show** commands to display the status of the new interface or all interfaces, or to verify changes you have made.

Depending on the requirements for your system configuration and the protocols you plan to route on the interface, you might also need to enter other configuration subcommands. For complete descriptions of configuration subcommands and the configuration options available for FE interfaces, refer to the publications listed in the section “If You Need More Information” on page 2.

FE half-duplex operation is the default. To change to full-duplex operation, use the following series of commands:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#

Router(config)# interface fastethernet 3/0/0
Router(config-if)# full-duplex
Ctrl-z
Router#
```

---

**Note** Each FE interface on an FEIP2 can be configured at 100 Mbps, half duplex, for a maximum aggregate bandwidth of 200 Mbps per pair. Each FE interface on an FEIP2 can also be configured at 200 Mbps, full duplex, for a maximum aggregate bandwidth of 400 Mbps per pair. Further, one FE interface can be configured at 100 Mbps, half duplex, while the other FE interface can be configured at 200 Mbps, full duplex, for a maximum aggregate bandwidth of 300 Mbps per pair.

---

Using the **show interfaces fastethernet** command, you can see that the 3/0/0 FE interface is now configured for full-duplex operation:

```
Router# sh int fa 3/0/0
FastEthernet 3/0/0 is administratively up, line protocol is up

(display text omitted)

Encapsulation ARPA, loopback not set, keepalive not set, fdx, 100BaseTX
```

To return the interface to half-duplex operation, use the **no full-duplex** configuration command, as follows:

```
Router# config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# int fa 3/0/0
Router(config-if)# no full-duplex
Ctrl-z
Router#
```

Using the **show interfaces fastethernet** command, you can see that the 3/0/0 FE interface is now configured for half-duplex operation:

```
Router# sh int fa 3/0/0
FastEthernet3/0/0 is administratively up, line protocol is up

(display text omitted)

Encapsulation ARPA, loopback not set, keepalive not set, hdx, 100BaseTX

(display text omitted)
```

The RJ-45 connection is the default for FEIP2-2TX (or SC for FEIP2-2FX). To change to an MII connection and then verify it, use the following series of commands, including the **media-type** configuration command:

```
Router# config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# int fa 3/0/0
Router(config-if)# media-type mii
Ctrl-z

Router# sh int fa 3/0/0
FastEthernet3/0/0 is administratively up, line protocol is up

(display text omitted)

Encapsulation ARPA, loopback not set, keepalive not set, hdx, MII

(display text omitted)
```

Use the **media-type 100** configuration command to return the interface to its default state for RJ-45 or SC (fiber-optic) connections.

## Checking the Configuration

After configuring the new interface, use the **show** commands to display the status of the new interface or all interfaces and the **ping** command to check connectivity.

### Using show Commands to Verify the FEIP2 Status

The following steps use **show** commands to verify that the new interfaces are configured and operating correctly.

- Step 1** Use the **show version** command to display the system hardware configuration. Ensure that the list includes the new interfaces.
- Step 2** Display all the current interface processors and their interfaces with the **show controllers cbus** command. Verify that the new FEIP2 appears in the correct slot.
- Step 3** Specify one of the new interfaces with the **show interfaces type slot/adaptor/interface** command and verify that the first line of the display specifies the interface with the correct slot number. Also verify that the interface and line protocol are in the correct state: up or down.
- Step 4** Display the protocols configured for the entire system and specific interfaces with the **show protocols** command. If necessary, return to configuration mode to add or remove protocol routing on the system or specific interfaces.
- Step 5** Display the running configuration file with the **show running-config** command. Display the configuration stored in NVRAM using the **show startup-config** command. Verify that the configuration is accurate for the system and each interface.

If the interface is down and you configured it as up, or if the displays indicate that the hardware is not functioning properly, ensure that the network interface is properly connected and terminated. If you still have problems bringing the interface up, contact a service representative for assistance.

### Using show Commands to Display Interface Information

To display information about a specific interface, use the **show interfaces** command with the interface type and port address in the format **show interfaces [type slot/adaptor/port]**.

Following is a partial-display example of how the **show interfaces** command displays status information (including the physical slot and port address) for the interface you specify. In this example, most of the status information for each interface is omitted, and an FE interface in interface processor slot 3 is shown:

```
Router# sh int fastethernet 2/0/0
FastEthernet2/0/0 is administratively down, line protocol is down
  Hardware is cyBus FastEthernet Interface, address is 0000.0ca5.2380 (bia 0000)
  MTU 1500 bytes, BW 100000 Kbit, DLY 100 usec, rely 255/255, load 1/255
  Encapsulation ARPA, loopback not set, keepalive set (10 sec), hdx, 100BaseTX

(additional displayed text omitted from this example)
```

With the **show interfaces** [*type slot/adaptor/port*] command, use arguments such as the interface type (fastethernet, and so forth) and the port number (slot/port) to display information about a specific interface only, as in the following example of the **show interfaces fastethernet** command, which shows information specific to the first FE interface on an FEIP2 in interface processor slot 2:

```
Router# show interfaces fastethernet 2/0/0
FastEthernet2/0/0 is administratively down, line protocol is down
  Hardware is cyBus FastEthernet Interface, address is 0000.0ca5.2380 (bia 0000)
  MTU 1500 bytes, BW 100000 Kbit, DLY 100 usec, rely 255/255, load 1/255
  Encapsulation ARPA, loopback not set, keepalive set (10 sec), hdx, 100BaseTX
  ARP type: ARPA, ARP Timeout 4:00:00
  Last input 3:08:43, output 3:08:42, output hang never
  Last clearing of "show interface" counters 2:58:36
  Output queue 0/40, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
    0 packets input, 0 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants
    0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
    0 watchdog, 0 multicast
    0 input packets with dribble condition detected
    0 packets output, 0 bytes, 0 underruns
    0 output errors, 0 collisions, 0 interface resets, 0 restarts
    0 babbles, 0 late collision, 0 deferred
    0 lost carrier, 0 no carrier
    0 output buffer failures, 0 output buffers swapped out
```

(additional displayed text omitted from this example)

The **show controllers cbus** command displays information about all of the interface processors in your router, including the FEIP2. Following is an example of the **show controllers cbus** command used with a Cisco 7500 series system:

```
Router# show controllers cbus
MEMD at 40000000, 2097152 bytes (unused 8256, recarves 1, lost 0)
RawQ 48000100, ReturnQ 48000108, EventQ 48000110
BufhdrQ 48000128 (2357 items), LovltrQ 48000148 (6 items, 1632 bytes)
IpcbufQ 48000158 (16 items, 4096 bytes)
IpcbufQ_classic 48000150 (8 items, 4096 bytes)
3570 buffer headers (48002000 - 4800FF10)
pool0: 11 buffers, 256 bytes, queue 48000130
pool1: 1168 buffers, 1536 bytes, queue 48000138
pool2: 4 buffers, 1568 bytes, queue 48000140

slot2: FEIP2, hw 2.4, sw 21.40, ccb 5800FF40, cmdq 48000090, vps 8192
  software loaded from system
  IOS (tm) VIP Software (SVIP-DW-M), Released Version 11.1(10)CA [biff 138]
  ROM Monitor version 17.0
  FastEthernet2/0/0, addr 0003.0b33.f540 (bia 0003.0b33.f540)
    gfreeq 48000138, lfreeq 480001C0 (1536 bytes), throttled 0
    rxlo 4, rxhi 438, rxcurr 0, maxrxcurr 2
    txq 48001A00, txacc 48001A02 (value 259), txlimit 259
  FastEthernet2/1/0, addr 0003.0b33.f548 (bia 0003.0b33.f548)
    gfreeq 48000138, lfreeq 480001C8 (1536 bytes), throttled 0
    rxlo 4, rxhi 438, rxcurr 0, maxrxcurr 0
    txq 48001A08, txacc 48001A0A (value 0), txlimit 259
```

(additional displayed text omitted from this example)

The **show version** (or **show hardware**) command displays the configuration of the system hardware (the number of each interface processor type installed), the software version, the names and sources of configuration files, and the boot images.

Following is an example of the **show version** command used with a Cisco 7500 series system:

```
Router# show version
Cisco Internetwork Operating System Software
IOS (tm) GS Software (RSP-JV-M), Released Version 11.1(10)CA [biff 135]
Copyright (c) 1986-1997 by cisco Systems, Inc.
Compiled Mon 10-Mar-97 10:06 by biff
Image text-base: 0x600108A0, data-base: 0x60982000

ROM: System Bootstrap, Version 11.1(2) [biff 2], RELEASE SOFTWARE (fc1)
ROM: GS Bootstrap Software (RSP-BOOT-M), Version 10.3(8), RELEASE SOFTWARE (fc2)

Router uptime is 23 minutes
System restarted by reload
System image file is "biff/rsp-jv-mz", booted via tftp from 223.255.254.254

cisco RSP2 (R4600) processor with 32768K bytes of memory.
R4700 processor, Implementation 33, Revision 1.0
Last reset from power-on
G.703/E1 software, Version 1.0.
SuperLAT software copyright 1990 by Meridian Technology Corp).
Bridging software.
X.25 software, Version 2.0, NET2, BFE and GOSIP compliant.
TN3270 Emulation software (copyright 1994 by TGV Inc).
Chassis Interface.

(additional displayed text omitted from this example)

1 FEIP2 controller (2 FastEthernet).
2 FastEthernet/IEEE 802.3 interfaces.

(additional displayed text omitted from this example)

123K bytes of non-volatile configuration memory.

8192K bytes of Flash PCMCIA card at slot 0 (Sector size 128K).
8192K bytes of Flash internal SIMM (Sector size 256K).
No slave installed in slot 7.
Configuration register is 0x0
```

To determine which type of interfaces are installed on an FEIP2 in your system, use the **show diag slot** command. Specific interface information is displayed, as shown in the following example of an FEIP2 in interface processor slot 2:

```
Router# show diag 2
Slot 2:
Physical slot 2, ~physical slot 0xD, logical slot 2, CBus 0
Microcode Status 0x4
Master Enable, LED, WCS Loaded
Board is analyzed
Pending I/O Status: None
EEPROM format version 1
FEIP2 controller, HW rev 2.4, board revision D0
Serial number: 03700746 Part number: 73-1684-03
Test history: 0x00 RMA number: 00-00-00
Flags: cisco 7000 board; 7500 compatible

EEPROM contents (hex):
0x20: 01 20 02 04 00 38 78 0A 49 06 94 03 00 00 00 00
0x30: 68 00 00 03 00 00 00 00 00 00 00 00 00 00 00 00

Slot database information:
Flags: 0x4 Insertion time: 0x9B8 (00:17:10 ago)

Controller Memory Size: 8 MBytes DRAM, 1024 KBytes SRAM

PA Bay 0 Information:
Fast-Ethernet PA, 1 ports, 100BaseTX-ISL
EEPROM format version 1\
HW rev 1.0, Board revision A0
Serial number: 04622911 Part number: 73-1688-03

PA Bay 1 Information:
Fast-Ethernet PA, 1 ports, 100BaseTX-ISL
EEPROM format version 1
HW rev 1.0, Board revision A0
Serial number: 03540609 Part number: 73-1688-03
```

In the preceding example, the two FE interfaces on the FEIP2 are clearly marked *100BaseTX*.

For additional Fast Ethernet command descriptions and examples, refer to the publications listed in the section “If You Need More Information” on page 2.

### Using the ping Command to Verify Network Connectivity

The *packet internet groper* (**ping**) command allows you to verify that an interface port is functioning properly and to check the path between a specific port and connected devices at various locations on the network. This section provides brief descriptions of the **ping** command. After you verify that the system and FEIP2 have booted successfully and are operational, you can use this command to verify the status of interface ports. Refer to the publications listed in the section “If You Need More Information” on page 2, for detailed command descriptions and examples.

The **ping** command sends an echo request out to a remote device at an IP address that you specify. After sending a series of signals, the command waits a specified time for the remote device to echo the signals. Each returned signal is displayed as an exclamation point (!) on the console terminal; each signal that is not returned before the specified time-out is displayed as a period (.). A series of exclamation points (!!!!!) indicates a good connection; a series of periods (.....) or the messages [timed out] or [failed] indicate that the connection failed.

Following is an example of a successful **ping** command to a remote server with the address 1.1.1.10:

```
Router# ping 1.1.1.10 <Return>
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echoes to 1.1.1.10, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/15/64 ms
Router#
```

If the connection fails, verify that you have the correct IP address for the server and that the server is active (powered on), and repeat the **ping** command.

For complete descriptions of interface subcommands and the configuration options available for FEIP2-related interfaces, and which support FEIP2 functionality, refer to the publications listed in the section “If You Need More Information” on page 2.

## Upgrading FEIP2 Microcode

The Cisco 7000 series and Cisco 7500 series routers support downloadable microcode, which allows you to upgrade microcode versions over the network. You can download new microcode versions and store multiple versions in Flash memory, and you can then boot from them just as you can with the system software images. System software upgrades might also contain upgraded microcode images, which load automatically when the new software image is loaded (unless the configuration states otherwise).

---

**Note** Software and interface processor microcode images are carefully optimized and bundled to work together. Overriding the bundle can result in system incompatibilities. We recommend that you use the microcode included in the software bundle.

---

You can download microcode to Flash memory by copying the TFTP image of a microcode version to Flash memory. When the microcode image is stored in Flash memory, you have to configure the router to use that image via the **microcode vip2 flash** command, then you can use the **microcode reload** command to manually load the new microcode file. You can then use the **configure** command to instruct the system to load the new image automatically at each system boot.

---

**Note** The appropriate microcode image runs from dynamic random-access memory (DRAM) on the FEIP2.


---

To compare the size of the microcode image and the amount of Flash memory available, you must know the size of the new microcode image. The image size is specified in the README file that is included on the floppy disk with the new image.

---

**Note** Note the size of the new image before proceeding to ensure that you have sufficient available Flash memory for the new image.

---



Follow these steps to download (copy) a microcode version from a TFTP server to Flash memory:

- Step 1** To display the total amount of Flash memory present, its location, any files that currently exist in Flash memory and their size, and the amount of Flash memory remaining, use the **show flash** command. Following is an example of the output that is displayed:

```
Router# show flash

-#- ED --type-- --crc--- -seek-- nlen -length- ----date/time----- name
1  \ FFFFFFFF B4A18E0B 3F6494 30 4023316 Jun 26 1994 19:44:29 image/file/1
2  .. FFFFFFFF 8075AA5D 4118B4 23 111518 Jun 29 1994 11:05:57 image/file/2

12044568 bytes available (8533736 bytes used)
```

- Step 2** Compare the amount of available Flash memory (last line in the preceding example) to the size of the new microcode image on the floppy disk. If you attempt to copy in a new image, and the size of the new image exceeds the available space in Flash, only part of the new image is copied, and the following error message is displayed:

buffer overflow - xxxx/xxxx

where *xxxx/xxxx* is the number of bytes read in/number of bytes available.

- Step 3** After you verify that there is sufficient space available in Flash memory for the new image, use the command **copy tftp:filename [ flash | slot0 | slot1 ]:filename** to copy an image to Flash memory. (**tftp:filename** is the file's source and **[flash | slot0 | slot1]:filename** is the destination in onboard Flash memory or on either of the Flash memory cards.)

An example of the **copy tftp:filename** command follows:

[illegible]

- Step 4** Use the **show flash** command to verify that the microcode has been copied to Flash. The output should display the filename of the image you copied to Flash (*vip11-1* in the following example):

```
Router# show flash

#- ED --type-- --crc--- -seek-- nlen -length- ----date/time----- name
1  .. FFFFFFFF B4A18E0B 3F6494 30 4023316 Jun 26 1994 19:44:29 image/file/1
2  .. FFFFFFFF 8075AA5D 4118B4 23 111518 Jun 29 1994 11:05:57 image/file/2
3  .. FFFFFFFF EEA1FEEB 8436E8 22 600516 Oct 10 1995 19:35:25 vip11-1

7646052 bytes available (16179788 bytes used)
```



- Step 5** To ensure that the new microcode is used when you reboot the system, add the appropriate commands to the configuration file. To modify the configuration file, enter configuration mode by issuing the **configure terminal** command as follows:

```
Router# config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#
```

- Step 6** Specify that you are changing the microcode for the FEIP2 (*microcode vip2*), and that it is to load from Flash memory (*flash slot0* or *slot1*). Then add the filename of the new microcode image to be loaded from Flash:

```
Router(config)# microcode vip2 flash slot0:vip11-1
```

- Step 7** To exit configuration mode, press **Ctrl-Z**.

- Step 8** Copy the new configuration to nonvolatile random-access memory (NVRAM):

```
Router# copy running-config startup-config
```

The **microcode reload** command is automatically added to your running configuration. The new FEIP2 microcode image is loaded automatically the next time the system boots or reinitializes.

- Step 9** To load the new microcode immediately, you can issue the **microcode reload** configuration command (you must be in configuration mode to enter this command):

```
Router# config t
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)# microcode reload
```

Immediately after you enter the **microcode reload** command and press **Return**, the system reloads all microcode. configuration mode remains enabled; after the reload is complete, press **Ctrl-Z** to exit from configuration mode and return to the system prompt.

- Step 10** To verify that the FEIP2 is using the correct microcode, issue the **show startup-config** or **show controllers cbus** command, which indicates the currently loaded and running microcode version for each interface processor.

```
Router# show controllers cbus
```

This completes the procedure for downloading microcode to Flash memory.

## Cisco Connection Online

Cisco Connection Online (CCO) is Cisco Systems' primary, real-time support channel. Maintenance customers and partners can self-register on CCO to obtain additional information and services.

Available 24 hours a day, 7 days a week, CCO provides a wealth of standard and value-added services to Cisco's customers and business partners. CCO services include product information, product documentation, software updates, release notes, technical tips, the Bug Navigator, configuration notes, brochures, descriptions of service offerings, and download access to public and authorized files.

CCO serves a wide variety of users through two interfaces that are updated and enhanced simultaneously: a character-based version and a multimedia version that resides on the World Wide Web (WWW). The character-based CCO supports Zmodem, Kermit, Xmodem, FTP, and Internet e-mail, and it is excellent for quick access to information over lower bandwidths. The WWW version of CCO provides richly formatted documents with photographs, figures, graphics, and video, as well as hyperlinks to related information.

You can access CCO in the following ways:

- WWW: <http://www.cisco.com>
- WWW: <http://www-europe.cisco.com>
- WWW: <http://www-china.cisco.com>
- Telnet: [cco.cisco.com](http://cco.cisco.com)
- Modem: From North America, 408 526-8070; from Europe, 33 1 64 46 40 82. Use the following terminal settings: VT100 emulation; databits: 8; parity: none; stop bits: 1; and connection rates up to 28.8 kbps.

For a copy of CCO's Frequently Asked Questions (FAQ), contact [cco-help@cisco.com](mailto:cco-help@cisco.com). For additional information, contact [cco-team@cisco.com](mailto:cco-team@cisco.com).

---

**Note** If you are a network administrator and need personal technical assistance with a Cisco product that is under warranty or covered by a maintenance contract, contact Cisco's Technical Assistance Center (TAC) at 800 553-2447, 408 526-7209, or [tac@cisco.com](mailto:tac@cisco.com). To obtain general information about Cisco Systems, Cisco products, or upgrades, contact 800 553-6387, 408 526-7208, or [cs-rep@cisco.com](mailto:cs-rep@cisco.com).

---

---

This document is to be used in conjunction with the installation and configuration guide that shipped with your router. (4200fep2.fm[78-4200-03])

AAccessPath, AtmDirector, Cache Director System, the CCIE logo, CD-PAC, Centri, Centri Bronze, Centri Gold, Centri Security Manager, Centri Silver, the Cisco Capital logo, Cisco IOS, the Cisco IOS logo, *CiscoLink*, the Cisco Powered Network logo, the Cisco Press logo, ClickStart, ControlStream, Fast Step, FragmentFree, IGX, JumpStart, Kernel Proxy, LAN<sup>2</sup>LAN Enterprise, LAN<sup>2</sup>LAN Remote Office, MICA, Natural Network Viewer, NetBeyond, Netsys Technologies, *Packet*, PIX, Point and Click Internetworking, Policy Builder, RouteStream, Secure Script, SMARTnet, StrataSphere, StrataSphere BILlder, StrataSphere Connection Manager, StrataSphere Modeler, StrataSphere Optimizer, Stratm, StreamView, SwitchProbe, *The Cell*, TokenSwitch, TrafficDirector, VirtualStream, VlanDirector, Workgroup Director, Workgroup Stack, and XCI are trademarks; The Network Works. No Excuses. is a service mark; and BPX, Catalyst, Cisco, Cisco Systems, the Cisco Systems logo, EtherChannel, FastHub, FastPacket, ForeSight, IPX, LightStream, OptiClass, Phase/IP, StrataCom, and StrataView Plus are registered trademarks of Cisco Systems, Inc. in the U.S. and certain other countries. All other trademarks mentioned in this document are the property of their respective owners.

Copyright © 1997–1998, Cisco Systems, Inc.  
All rights reserved. Printed in USA.  
9711R